



EXPOSED SUBFLOOR TREATMENT



Bio-Enzymatic

- Step 1)** Set sprayer tip on fan pattern. Saturate all obvious stained areas.
- Step 2)** Set sprayer tip on pencil point pattern. Saturate the perimeter of each room spraying behind the tack strip and underneath the baseboard.
- Step 3)** Set sprayer tip on fan pattern. Saturate the entire subfloor, making sure to get 100% coverage to all areas. **Note: Apply enough product to darken the subfloor color.**
- Step 4)** Set sprayer tip on fan pattern. Spray perimeter of room concentrating on spraying the baseboard. **Lightly** spray the walls if you suspect animal marking. Safe to use on watersafe surfaces. Test an inconspicuous area before application on walls.
- Step 5)** Set thermostat fan to “run” (fan should be running full time). Set sprayer tip on very fine mist pattern and spray into each intake HVAC vent for 10 seconds.
- If subfloor is very heavily saturated with pet urine repeat step 2 and 3.
 - Flooring may be installed immediately after treatment is complete. If glue will be used in installation, allow Smell Zapper to dry completely.